Eddie Bauer

Sweater Fleece Full-Zip

PRODUCT MEASUREMENTS

	XS	S	М	L	XL	2XL	3XL	4XL
Body Length at Back	27	28	29	30	31	32	32.5	33
Chest Width	19.5	21	22.5	24	25.5	27	29	31
Bust	34.75	35.5	36.25	37	37.75	38.5	39.25	40

BODY LENGTH AT BACK

CHEST WIDTH

Measured from high point shoulder to finished hem back.

Measured across the chest one inch below armhole when laid flat.

SLEEVE LENGTH

Start at center of neck and measure down shoulder, down sleeve to hem.

SIZE CHART

	XS	S	М	L	XL	2XL	3XL	4XL
Body Length at Back	32-34	35-37	38-40	41-43	44-46	48-50	52-54	55-57

CHEST

With arms down at sides, measure around the upper body, under arms and over the fullest part of the chest.